



Introduction

Thank you for purchasing the Hurricane. Please read this User Guide to understand and ensure safe, proper, effective and responsible use of the Hurricane.


Safety Precautions

Please ensure you have read and fully understood the safety precautions before operating this appliance. For further in depth instructions please refer to the supplementary on-line user manual (www.hurricane-es.com).

Instructions for use of this product will vary depending on chemical applications. Always read the product label when preparing your solution.

- Always comply with any requirements for Personal Protective Equipment (PPE) as required by the formulation label.
- This appliance is to be kept out of reach from children. However, it can be used by children aged 8 years and above, as well as persons with reduced physical, sensory or mental capacities or lack of experience and knowledge, provided they have been given supervision or instruction concerning use of the appliance in a safe way, and understand the hazards involved.
- Children should not play with the appliance, and cleaning and user maintenance should not be made by children without supervision.
- Children should be supervised to ensure they do not play with the appliance.
- Users should hold the appliance and manually cover the designated fogging areas.
- The fogger should not be left operating unattended, and for the most efficient application it should not be left stationary.
- This fogger can be used with water-based, oil-based, and solvent-based formulations.
- Never direct fogging at live electrical items, animals, humans, etc. Remember to cover aquariums before fogging takes place.

Please take note of the below diagram to familiarise yourself with the design and structure of the unit:



Operation

- Ensure you are wearing appropriate PPE when operating this fogger.
- If the use of an extension lead is required, ensure it is rated at 230V 13A and is grounded. Only use an extension lead which is properly rated for voltage, current, length, and which is free from nicks, cracks, and other signs of prior abuse. Replace damaged or worn electric leads immediately.
- Do not use a fogger that is broken or damaged in any way. Do not alter the fogger by adding or removing parts.
- Do not restrict the motor blower air intake area.

Formulation

- Always read the product label when preparing your solution and ensure the formulation is suitable for the intended application.
- This fogger can be used with water-based, oil-based, and solvent-based formulations. Ensure that formulation is applied only in strict compliance with the formulation label and store formulation in its original labelled container.
- Remove the filling cap to pour formulation into the tank. Add only premixed/diluted formulations to the tank.

Operation

- With the fogger power off, remove the filling cap and pour your premixed formulation into the tank, up to a maximum 3.8 litres, and replace the cap.
- Ensuring the fogger is pointing in a safe direction, turn on via the power switch and select the appropriate flow rate.
- The exact method of operation is dependent on a number of factors, including the application, flow rate, formulation viscosity, but best results are normally achieved maintaining a distance of 1-4 metres from the items you want to fog. Keep moving the fogger with slow, steady movements for an even coverage, starting from the highest point. If there is liquid run-off then the application is too heavy, either move further away, adjust the flow rate or speed up.
- Do not allow the fogger to operate unattended. Do not stand in water or hold over water while operating fogger and do not allow the power lead or extension lead to be submersed in water. Do not use outdoors when it's raining.
- Do not block the air intake area.

Flow Rate Information

- Thicker viscosity liquids will flow at lower rates and produce a bigger droplet size.
- Adjusting the valve will regulate flow rate.
- When the valve is turned clockwise, flow rate will reduce; when turned anti-clockwise, flow rate will increase.

After Use

- Turn the flow valve OFF after each fogging application while the motor is still operating to allow the clearing of the lines.
- Turn off the appliance before unplugging. Unplug by grasping the plug, do not pull on the lead to unplug. Do not unplug the fogger with wet hands.
- Clean the Air Intake Filter after each application. If the filter becomes saturated while the fogger is in operation, switch it off and clean the filter.
- Formulation should not be stored in the tank. The tank should be cleaned after each use with hot water with a detergent solution and flushed thoroughly with clean water before re-use. To ensure a full flush, fully open the valve and operate the fogger for 3 to 5 minutes.

Wiring Instructions

The wires in the mains lead are coloured in accordance with the following code:

BLUE = NEUTRAL

BROWN = LIVE

YELLOW & GREEN = EARTH

As the colours of the wire in the mains lead of this appliance may not correspond with the colour marking identifying the terminals on your plug, proceed as follows:

- The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N.
- The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L.
- The wire which is coloured YELLOW & GREEN must be connected to the terminal which is marked with the letter E or the symbol ⊕.

For UK

This appliance is supplied fitted with a BS1363 mains plug and a BS1362 10A fuse. If this plug is removed from the appliance, please ensure it is disposed of safely as a disconnected plug is dangerous if reconnected to the mains. If any other type of plug is used, a 10A fuse must be fitted.

For EU

This appliance is supplied fitted with a Schuko mains plug. If this plug is removed from the appliance, please ensure it is disposed of safely as a disconnected plug is dangerous if reconnected to the mains.

For private households: Information on Disposal for Users of WEEE

This symbol (Figure. 1) on the product(s) and / or accompanying documents means that used electrical and electronic equipment

(WEEE) should not be mixed with general household waste.

For proper treatment, recovery and recycling, please take this product (s) to designated collection points where it will be accepted free of charge.

Alternatively, in some countries, you may be able to return your products to your local retailer upon purchase of an equivalent new product.

Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling.

Please contact your local authority for further details of your nearest designated collection point.

Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.

For professional users in the European Union

If you wish to discard electrical and electronic equipment (EEE), please contact your dealer or supplier for further information.

For disposal in countries outside of the European Union

This symbol is only valid in the European Union (EU). If you wish to discard of this product, please contact your local authorities or dealer and ask for the correct method of disposal.



Figure. 1

